

ONE IR Remote Codes

All codes are RC-5.

Function	Decimal command code
Standby	21 12
Mute Toggle	21 13
Power On	21 14
Power Off	21 15
Volume Up	21 16
Volume Down	21 17
Back	21 19
Source	21 20
Info	21 21
Bass +	21 22
Bass –	21 23
Treble +	21 24
Treble –	21 25
Balance R	21 26
Balance L	21 27
Random	21 28
Repeat	21 29
Alarm Set	21 30
Sleep	21 31
Skip Right	21 32
Skip Left	21 33
Prog	21 36
Brightness	21 40
>>	21 43
<<	21 44

Cambridge Audio

Function	Decimal command code
Eject	21 45
Tuning Mode	21 46
Play/Pause	21 47
Pause	21 48
Mute	21 50
UnMute	21 51
Menu	21 52
Play	21 53
Stop	21 54
Select/Enter	21 55
Aux In	21 56
CD	21 57
DAB	21 58
FM	21 59
Bluetooth	21 60
USB Audio	21 61
Digital Optical	21 62
Digital Coax	21 63

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to contact us at: <http://support.cambridgeaudio.com/>

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© Copyright Cambridge Audio Ltd 2014