



Azur 350A/C IR Remote Control Codes

350C CD Commands

System Code = 20 (RC-5 Code)

Key	Command Code dec
Open/Close	45
CD Player on	50
CD Player off	51
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/--	14
0	0
Prog	36
Skip left	33
Play	53
Skip right	32
<<	44
Stop	54
>>	43
Info	21
Pause	48
LCD Bright	40
Remain	61
Random	28
Repeat	29
LCD All segments On/Off	57



350A Amplifier Commands

System Code = 16 (RC-5 Code)

Key	Command Code dec
MP3	2
CD	5
Tuner/DAB	3
DVD	1
Aux	4
Tape Mon	0
Vol +	16
Vol -	17
Mute	13
Amp on	14
Amp off	15

Note the Discrete Mute On and Off and Power On and Off codes which don't have dedicated buttons on the remote are actually available from the remote by special procedure, see product manual.

Also incorporates Apple iPod codes

System Code = EE 87 (NEC Code)

Key	Command Code (hex/dec)
Skip back	08
Play/pause	04
Skip forward	07
Menu (stop)	02

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to email us at: www.cambridgeaudio.com/sts

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© Copyright Cambridge Audio Ltd 2008