
TVB2 SOUNDBAR & WIRELESS SUB

Quick Start Guide

Placement

The TVB2 soundbar can be fixed to a wall under your TV or placed on a stable surface in front of it.




Subwoofer Connection

The wireless subwoofer will automatically connect to the TVB2 soundbar. Simply plug in the subwoofer and turn on the sound bar – initial connection will take around 60 seconds. If the TVB2 soundbar is unable to connect to the subwoofer 'NOSUB' will be shown on the display.

TV Connections

Only one audio connection to your TV is required, in order of preference:

- 1. HDMI Out (ARC): If your TV has a HDMI socket labelled ARC use this connection.
- 2. Optical: Use this as an alternative digital connection if HDMI ARC is not available on your TV.



HDMI Connections




Learning your TV remote

(when using Optical or AUX In connections)

- 1. To learn the Vol+ button on your TV remote, press and hold the and + button on TVB2 for 2 seconds. 'LEARN' and 'VOL +' will flash on the display. Then double press the Vol+ button on your TV remote remembering to point it at TVB2's display.
- 2. To learn the Vol- button on your TV remote, press and hold the button on TVB2 for 2 seconds. 'LEARN' and 'VOL-' will flash on the display. Then double press the Vol- button on your TV remote remembering to point it at TVB2's display.

When successfully learned, 'OK' will be shown on the display.



Please note: If using HDMI-ARC for TV audio, there is no need to learn the TV remote control volume commands into the TVB2. The TV sends these commands via the HDMI connection.

Bluetooth set-up


TVB2 is equipped with Bluetooth to allow wireless playback from any Bluetooth equipped phone, tablet or computer.

1. Select the Bluetooth son the remote and - T - will flash on the display.

SOUND SINCE 1968

2. To connect a Bluetooth device to TVB2, press and hold the button.

Consult the instructions of the Bluetooth device to connect to TVB2. When successfully connected. 17 will stop flashing.



Once paired, music from your device will play through TVB2. To add another Bluetooth device, repeat from step 2. TVB2 will store up to 99 paired devices in memory.

If your Bluetooth device is NFC enabled

You may need to ensure Bluetooth is enabled on your device. Touch your NFC device against the logo on the side of TVB2. TVB2 will enter automatic pairing mode and 'TVB2 Cambridge' should appear on your device.

TOP TIPS

Auto power down

To save power, TVB2 will automatically turn off after a few minutes (for Bluetooth input the auto power down time is 20 minutes) if no sound is playing from your TV.

Auto Power On

When you turn on your TV, TVB2 will detect the sound and automatically turn on.

Subwoofer level

You can adjust the subwoofer level to suit your preference using the $\mbox{SUB+/-}$ buttons on the remote.

Sound Modes

There are 4 different modes that can be selected to enhance your sound experience.

TV : Greatly improved TV sound

Music: Enhances stereo music and music videos,
Film: Designed to get the best sound from movies,
Voice: Enhances voices to improve intelligibility.

