



Azur 752BD Blu-ray Remote Control Codes

NEC Code: 49 B6

Button	IR Code	Hidden	
Backlight	N/A		
Open/Close	0C F3		
On/Standby toggle	04 FB	13 EC	1A E5
Info	0E F1		
1	14 EB		
2	08 F7		
3	00 FF		
Page Up	10 EF		
4	05 FA		
5	09 F6		
6	01 FE		
Page Down	11 EE		
7	19 E6		
8	15 EA		
9	0D F2		
Home	12 ED		
0	0A F5		
Go To	06 F9		
Clear	02 FD		
Volume Up	4C B3		
◀◀ (Skip Back)	07 F8		
▲ (Up)	48 B7		
▶▶ (Skip Fwd)	0F F0		
■ (Stop)	52 AD		
◀ (Left)	42 BD		
Enter	4D B2		
▶ (Right)	41 BE		
▶/□ (Play/Pause)	51 AE		
◀◀ (Scan Back)	1B E4		
▼ (Down)	55 AA		
▶▶ (Scan Fwd)	0B F4		
Volume Down	46 B9		

Top Menu	50 AF	
Pop Up Menu	40 BF	
Setup Menu	54 AB	
Return	49 B6	
Pure Audio	45 BA	
Filter	2A D5	
Sound Track	56 A9	
Subtitle	57 A8	
● (Red)	44 BB	
● (Green)	58 A7	
● (Yellow)	03 FC	
● (Blue)	17 E8	
Digital Inputs	2B D4	
Options	23 DC	
A/B	4F B0	
Repeat	53 AC	
3D	22 DD	
DIM	24 DB	
Angle	4B B4	
Zoom	43 BC	
Res	4A B5	
TV Type	16 E9	

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to email us at: support@cambridgeaudio.com

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© 2013 Copyright Cambridge Audio Ltd