



## Azur 651/751R AV Receiver Remote Control Codes

All numbers are in decimal format  
RC5 System Code 16

Command	System Code 16
TUNER AM/FM TOGGLE	64
TUNER AM	108
TUNER FM	109
BD/DVD	65
VIDEO1	66
VIDEO2	67
REC1	68
AUX	69
CD	70
REC2	71
<b>USB**</b>	<b>72</b>
VIDEO3/MP3	73
POWER TOGGLE	74
POWER ON	100
POWER STANDBY	101
MUTE TOGGLE	75
MUTE	102
UNMUTE	103
VOL/MENU UP	76
VOL/MENU DOWN	77
ANALOG STEREO DIRECT	78
DIGITAL STEREO MODES	79
SURROUND MODES	80
ZONE 2	81
TRIGGER A	82
TRIGGER B	83
EXP	84
BRIGHTNESS	85
INFO	86
TUNER STEREO/MONO TOGGLE	87
TUNER STEREO	104
TUNER MONO	105
TUNER STORE	88
TUNER MODE	89
LEFT	90
ENTER	91
RIGHT	92
OSD ON OFF	93
BASS/TREBLE	94

**\*\*Only on 751R handset**

<b>Command</b>	<b>System Code</b>
7.1 DIRECT	95
AUDIO INPUT TYPE	96
PIC ADJ	97
INPUT_SELECT	99
LIP SYNC	127

Information in this document has been carefully checked for accuracy; however, Cambridge Audio's policy is one of continuous improvement, therefore design and specifications are subject to change without prior notice. If you notice any errors please feel free to email us at: [support@cambridgeaudio.com](mailto:support@cambridgeaudio.com)

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© 2013 Copyright Cambridge Audio Ltd